

## Mitel NuPoint Voicemail Quick Reference Guide

### VOICEMAIL SYSTEM ACCESS AND MAILBOX NUMBER

The voicemail extension is pre-programmed on the Voicemail key. Use this key to access the voicemail system. Mailbox numbers are the same as the system assigned phone extension.

### INITIALIZING YOUR VOICE MAILBOX

1. Press the Voicemail key
2. A user tutorial will automatically activate. This tutorial will guide you through your first mailbox session. It will explain how to record a personal greeting and your name for the company directory, and prompt you to change your passcode.

### ACCESSING VOICEMAIL

*To access your mailbox if you do not have a new message*

1. Press Voicemail key or dial the voicemail extension
2. Enter passcode

*To access voicemail if your message light is flashing*

1. Lift the handset
2. Press the flashing Message button
3. Enter passcode

*To access voicemail from outside the office*

1. Dial your company's main number (or) your own direct number
2. When the Auto Attendant (Company Greeting) plays, press \*
3. Enter your mailbox number
4. Enter your passcode

### TRANSFER A CALL DIRECTLY TO A VOICEMAIL BOX

*To transfer a call to a voicemail box:*

1. Press Trans/Conf
2. Press Voicemail
3. Press \*
4. Enter the extension or mailbox number
5. Hang up immediately

### LISTENING TO VOICEMAIL MESSAGES

*When you access your mailbox, the system will tell you how many messages you have.*

Press  to Play the message

### MESSAGE OPTIONS

*After a message has finished playing, you have the following options:*

 Press 7 to re-play the message

 Press 2 to send a reply message

When finished, press 9 to send the response

 Press 4 to forward the message to another mailbox. Messages can be forwarded with or without comments.

 Press 5 to keep or save the message

 Press 3 to discard or delete the message

 Pressing the \* key immediately after discarding a message will recover the discarded message.